

How to Install the DT90K Aftercooler (new style)

The kit comes with an adapter, o-ring and 2 bolts.

The adapter will bolt on to the location of the aftercooler.

The elbow (with a compression fitting) will screw into the adapter.

The finned, copper line will connect to the elbow.

The other end of the line will connect to the unloader valve.

Note: This aftercooler typically mounts to the T39 pump on the 30 gallon gas-powered units.